

Notes:

- 1. Same procedure is used over any smooth roof to install the polyester fabric.
- 2. Urethane method requires material under and over. Resin base applies over the top.
- 3. For deck systems with urethane on plywood, reinforce joints only.

ADUREL POLYMAR ROOFING SYSTEMS

FIELD LINER DETAIL

AFL-1